

Firmware Upgrade

How to make an update disc

Write the downloaded file onto a blank CD- R disc, using the following settings.

- 1) Download the software update file from the Samsung Internet Site
(<http://www.samsung.com/Support/ProductSupport/Download/index.aspx>)
after checking your DVD player's Model name on the rear,
download a file using the "Search Your Model - Name" window.
- 2) Write the file to disc using CD- R driver of your computer.

- Software update file name: **UPDATE.VER** and **BUILD.IMG**
- **Please do not change the file name. If you change the file name, DVD player do not recognize the update CD- R.**


NOTE

- | Recommended Application Program
- Nero Burning / Easy CD Creator .. Etc
- | Option
- Multisession ; No Multisession
- CD close or Finalized CD
- | **In order to increase Disc Playability, add a dummy file (over 100MB) together with the update file in CD- R, not CD- RW.**
(The Dummy File can be used any kind of file except jpg, mp3, wma file. Zip file format is recommended.)

Firmware Upgrade

Update procedure

- 1) Insert the update CD- R disc with the software update.
- 2) It takes about 30 sec. to load the update disc.
- 3) Select the “TOTAL” and press the “ENTER” button on the remote control



NOTE

The display can be changed depend on its Version and without any notice.

4) It takes about 1 min. to complete the update.



“Do not turn off the player” will be displayed on the screen for update

5) After update is completed, the door tray will be open automatically.



6) Remove the update disc and wait for 2min.

The unit will shutdown automatically.

7) Turn on the unit with power button. The display will show the Menu Languages within a few seconds.



8) Select the languages you want with a corresponding number button. The update is now completed.