

English: (Deutsch siehe unten)
Release V2.0
-small bugfixes for AVI files(ASP profile)

Codefree Information on DVX-6700

1. Remove CD/DVD
2. Press „Setup“ and move with arrow keys to “Preference Page” option
3. Press 1,3,7,9 on remote control
4. Now use Up/Down keys to select the regioncode you like, „0“ means codefree
5. Press “Play/Select” to save
6. Press “Setup” to leave setup

Information on AVI subtitles:

To select the subtitle language just choose the subtitle language from Setup menu.
If you cannot choose your language, please select “other” then enter your language code.

The firmware supports the following languages:

1. English/ French (7082)/ German (6869)/ Italian (7384)/ Spanish (6983)
2. Polish (8076)/Czech (6783)/ Hungarian (7285)/ Romanian (8279)
3. Russian (8285)

Subtitle character limit is 60 characters, in case you have problems convert the subtitles using “Subtitles Workshop” or similar tools.

Filename of AVI and Subtitle file must be the same, like movie.avi and movie.srt/movie.sub

As you get the “Time” display all the time while playing AVI-files just press the “Display” button to disable it.

For selfmade CD/DVD make sure they are properly burned as ISO9660 Non-Multisession.

Multisession CD/DVD may not work properly. Also do not burn with WindowsXP integrated write option as it will create incompatible CD/DVD.

Please pay attention to the 1GB file length limitation. Files larger than 1GB may not play properly.

In case an AVI file will not work it is recommend to check if it is proper encoded.

You can easily convert Video files using a tool like from <http://divx.ppccool.com/>

Deutsch: (Deutsch siehe unten)

Version V2.0

-verbessert die Wiedergabe von AVI Dateien(ASP profile)

DVD Ländercode Information für DVX-6700

CD/DVD entfernen!

1. „Setup“ drücken, mit den Pfeiltasten auf „Preference Page/Seite bevorz. Einstell.“ wechseln.
2. Zahlen 1,3,7,9 auf der Fernbedienung eingeben
3. Nun mit den Pfeiltasten den Ländercode wählen.(“0” fuer alle)
4. “Play/Select” drücken zum speichern
5. “Setup” drücken zum beenden.

Die Zeit beim abspielen von AVI Dateien wird auf dem Bildschirm automatisch angezeigt, mit der “Display” Taste können sie diese Anzeige ausblenden.

Beachten sie bei selbsterstellten CD/DVD bitte darauf das diese im ISO9660 Format als Nicht-Multisession gebrannt wurden.

Multisession CD/DVD können mitunter nicht korrekt funktionieren.

Ebenso sollten sie keine CD/DVD mit der in WindowsXP eingebundenen Brennoption erstellen, solche CD/DVD laufen am PC aber nicht am DVD-Player.

Bitte beachten sie die maximale Dateilaenge von 1GB. Groessere Dateien werden evtl. nicht korret abgespielt.

Falls AVI Dateien nicht korrekt funktionieren, so vergewissern sie sich das diese ordnungsgemaess erstellt worden sind. Bei der Anfertigung/Umwandlung gibt es unzählige Einstellungen welche ggf. ein Abspielen nicht moeglich machen oder eine nur fehlerhafte Wiedergabe erzeugen auf einem DVD-Player.

Um solche Probleme auszuschliessen kann man die Daten sehr einfach konvertieren z.B mit einem Tool von welches sie auf der folgenden Webseite finden koennen: <http://divx.ppccool.com/>